
1. Overview



2. Installation Environment



Recommended Installation Location (shown as left figure): Install the device indoor at least 10 feet (3m) away from windows, and 6.5 feet (2m) away from light fixtures. It is not recommended to be installed close to the windows or outdoors.











Direct sunlight

Outdoors


- 1) Do not operate it with power.
- 2) We recommend that use the DC 12V/1.5A power supply.
- 3) Do not install the device in a place subject to direct sun light, humidity, dust or
- 4) Please read the terminals description carefully and wiring by rule strictly.
- 5) Please connect the GND before other wirings especially under the serious electrostatic environment

4. Device Installation


Mounting on the wall



- 1. Post the installation template on the wall and drill. The distance from baseline to the ground is 1.1m by recommendation (for height in 1.55m to 1.85m). If the distance is 1.2m, the suitable height for users is beyond 1.65m.
- 2. Fix the plate with the screws on the hole drilled in the wall.
- 3. Up down fix the device into the plate.
- 4. Fix the bottom screw.





6. Exit Button & Door Sensor Connection



7. Lock Relay Connection

The system supports Normally Opened Lock and Normally Closed Lock. The NO LOCK (normally opened at power on) is connected with 'NO' and 'COM' terminals, and the NC LOCK (normally closed at power on) is connected with 'NC' and 'COM' terminals. Take NC Lock as an example below:





8. Notifications

a. Recommended Method

b. Not Recommended Methods

1) Recommended Standing Position

Recommended using methods (shown as

left figures): During enrollment and

move the device, keep the same

recognition function will be poor.

installation height, or else, the

verification, the installation position of


device must remain the same. If need to

For users 5-6 feet tall (1.55m-1.85m), we recommend users

stand about 2 feet (0.5m) from the device. When viewing

your image on the device, step away if your image appears

too bright, and step closer if your image appears too dark.



Note: During enrollment and verification, try to have a relaxed face expression and stand upright.

2) Enrolling Expressions

- a. Please adjust your eyes into the green box by moving forward or backward while enrolling.
- b. Please adjust your face into the green box to make it in the screen center.







Press M/OK icon to enter the Main Menu > User Management > New User.



User ID: Enroll user ID; it supports 1-9 digits of numbers. Name: Enroll name; it supports 1-12 digits of any characters. Use Role: Select the user role (Normal User or Super Admin). Fingerprint: Enroll a fingerprint or fingerprints.

Face: Enroll a face according to the prompts of screen and voice. Badge Number: Enroll a badge by swiping a badge. Password: Enroll the password; it supports 1-9 digits of numbers. User Photo: Enroll the user photo which will be displayed after

Access Control Role: Set the Access Conrtol parameters of a user.

Press M/OK icon to enter the Main Menu > Comm. > Ethernet.

The Parameters below are the factory default values. Please adjust them according to the actual network.

IP Address: 192.168.1.201 Subnet Mask: 255 255 255 0 Gateway: 0.0.0.0

DNS: 0.0.0.0

TCP COMM. Port: 4370

DHCP: Dynamic Host Configuration Protocol, which is to dynamically allocate IP addresses for clients via server. If DHCP is enabled, IP cannot be set manually. Display in Status Bar: To set whether to display the network icon on the status bar.

11. WiFi Setting



Wireless Router

Access Control Terminal

Press M/OK icon to enter the Main Menu > Comm. > Wireless Network.

....

Press M/OK to enable WIFI, the device will search available WIFI in the network range



Select an available WIFI, enter the password input interface. Input password and press



Select the connected WIFI signal, press M/OK to view the IP address and other

12. T9 Input

T9 input (intelligent input) is quick and high efficient. The device support T9 English and symbol input. By using T9 input, names, user roles, short message and some symbols can be input (For example, input Jack as below figures show).

case [Aa], press numeric key

5 once to get letter J.



methods: mixed case, upper

case, lower Case, number

Press ► key to switch input Press ▶ key to select mixed



get letter a. Again, press numeric key 2 three times to get letter c. Press numeric key 5 twice to get letter k.

13. Problems & Solutions

- 1. The face is not recognized by the device while verification.
- a. Check out if the expressions or standing postures and distance is same in enrolling and verifying.
- b. Check out if the sunlight is direct to the device or if the device is near to the
- 2. Users do not wear glasses in enrolling and wear glasses in verifying. **Solutions:** You can enroll face wearing glasses during the first catching face for the device supports 2 times to catch the face templates.
- 3. The device makes a misjudgment while verification. **Solutions:** There is a certain probability of misjudgment, you can re-enroll the face. -7-

Quick Start Guide

Wireless Face Access Control Terminal

1) Recommended Installation Location



2) NOT Recommended Locations:




Direct sunlight





light fixtures

3. Cautions













verification. 10. Ethernet Setting









